

251



ADL100-EY, ADL300-EY

Installation and operation instruction V2.2

**ACREL Co.,Ltd**

## Declare

The copyright is the property of Acrel. Any information in any paragraph or section cannot be extracted, copied or otherwise reproduced or propagated. Otherwise offenders shall take all consequences.

All rights are reserved.

Acrel reserves the right to modify the product specifications herein without notification. Please consult the local agent about the latest specifications before placing a purchase order.

# Content

|   |                                    |   |
|---|------------------------------------|---|
| 1 | General.....                       | 1 |
| 2 | Product specification.....         | 1 |
| 3 | Main function.....                 | 1 |
| 4 | Technical parameter.....           | 2 |
| 5 | Dimension drawings (Unit: mm)..... | 2 |
| 6 | Wiring and installing.....         | 3 |
| 7 | Display and operation.....         | 4 |
| 8 | Communication description.....     | 4 |

## 1 General

ADL100-EY single phase pre-paid meters with intro-control, ADL300-EY three phase pre-paid meters with intro-control are used for calculating the single and three phase active energy respectively on the frequency of 50 Hz. The meter has functions of pre-paid, load controlling and RS485 communication etc. meet the related technical requirements of electronic power meter in the IEC62053-21, IEC62053-22 standards.

## 2 Product specification

| Type      | Accuracy class | Reference voltage (V) | Current (A) | Pulse constant (imp/kWh) |
|-----------|----------------|-----------------------|-------------|--------------------------|
| ADL100-EY | 1              | 220V                  | 10 (60) A   | 1600                     |
| ADL300-EY | 0.5s           | 3×220/380V            | 3×1 (6) A   | 6400                     |
|           |                |                       | 3×10 (80) A | 400                      |

## 3 Main function

| Function name                        | ADL100-EY   | ADL300-EY                               | Function provide |
|--------------------------------------|---|---|------------------|
| Measurement of kWh                   | Total active energy kWh (positive and negative in total)                |   | ■                |
| Measurement of electrical parameters | U、I、P、Q、S、PF、F  |   | ■                |
| Pre-paid mode                        | Through RS485 communication prepaid recharge, data encryption           |   | ■                |
| Control                              | Built-in high-capacity sub-holding relay to achieve load on-off control |   | ■                |
| LCD display                          | 8 bits section LCD display  |   | ■                |
| Communication                        | Communication interface: RS485, Communication protocol: MODBUS-RTU      |   | ■                |
| Multi-tariff                         | 4 tariff rates, 14 time interval by day                                 | 4 tariff rates, 14 time interval by day | □F               |

( ■: means standard; □: means optional)

**Note: Pre-paid mode function can only be achieved with the pre-paid system which designed by Acrel Co.,Ltd.**

## 4 Technical parameter

### 4.1 Electric performance

| Technical parameter     |                       | ADL100-EY   | ADL300-EY               |
|-------------------------|-----------------------|---|-------------------------|
| Voltage                 | Reference voltage     | 220V  | 3×220/380V              |
|                         | Reference frequency   | 50Hz  |                         |
|                         | Consumption           | <4VA(Each phase)                                    |                         |
| Current                 | Input current         | 10(60)A   | 1(6)A ,10(80)A          |
|                         | Starting current      | Connect directly: 0.004 Ib, connect via CT: 0.002In |                         |
|                         | Consumption           | <4VA (Maximum current)                              |                         |
| Measurement performance | Accuracy of measuring | 1 Class   | 0.5s Class              |
| Clock accuracy          |                       | Error ≤0.5s/d                                       |                         |
| Active pulse            | Pulse width           | 80ms±20ms   |                         |
|                         | Pulse constant        | 1600imp/kWh   | 6400imp/kWh,400 imp/kWh |
| Communication           | Interface             | RS485(A+、B-)  |                         |
|                         | Connection mode       | Shielded twisted pair conductors                    |                         |
|                         | Protocol              | MODBUS-RTU  |                         |

### 4.2 Mechanical performance


|   | ADL100-EY         | ADL300-EY       |
|---|-------------------|-----------------|
| Outline (Length × Width × Height)       | 72mm×88mm×70mm    | 144mm×88mm×70mm |
| Maximum wiring ability (flexible cable) | 25mm <sup>2</sup> |                 |

### 4.3 Work environment


|                   |                     |                       |
|-------------------|---------------------|-----------------------|
| Temperature range | Work temperature    | -25℃~55℃              |
|                   | Storage Temperature | -40℃~70℃              |
| Relative humidity |                     | ≤95%(No condensation) |
| Altitude          |                     | <2000m                |

## 5 Dimension drawings (Unit: mm)


ADL100-EY



ADL300-EY




direct connect




connect via CT

**Note:** The torque of direct connect should not be greater than 4.0N·m, and the torque of connect via CT should not be greater than 2.0N·m.


## 6 Wiring and installing




ADL100-EY



ADL300-EY Three phase four lines direct connect



ADL300-EY Three phase four lines connect via CT



Auxiliary function

## 7 Display and operation


### 7.1 Display examples




dump energy



Total energy



Voltage display



Current Display

## 8 Communication description

### 8.1 Communication protocol

The meters adapt Modbus 1. Please refer to the relevant standards for more information. The multi-tariff data mean nothing when multi-tariff function (F) is not applied.

### 8.2 MODBUS address table

#### ADL100-EY address table

| Address | Variable                    | Length | R/W | Notes         |
|---------|-----------------------------|--------|-----|---------------|
| 0000H   | Current total active energy | 4      | R   | unit: 0.01kWh |

|                       |   |   |     |   |
|-----------------------|---|---|-----|---|
| 0002H                 | Current spike active energy                             | 4 | R   |   |
| 0004H                 | Current peak active energy                              | 4 | R   |   |
| 0006H                 | Current flat active energy                              | 4 | R   |   |
| 0008H                 | Current valley active energy                            | 4 | R   |   |
| 000AH                 | Code  | 2 | R/W |   |
| 000BH                 | U Voltage   | 2 | R   |   |
| 000CH                 | I Current   | 2 | R   |   |
| 000DH                 | P Active power  | 2 | R   | unit: 0.001Kw   |
| 000EH                 | Q Reactive power  | 2 | R   | unit: 0.001Kvar   |
| 000FH                 | S Apparent power  | 2 | R   | unit: 0.001Kva  |
| 0010H                 | PF Power factor   | 2 | R   | Calculation factor: 0.001 (-1000~1000) effective range (-1000~1000)                       |
| 0011H                 | Frequency   | 2 | R   | unit: 0.01Hz  |
| 0012H                 | Year, month   | 2 | R/W |   |
| 0013H                 | Day, hour   | 2 | R/W |   |
| 0014H                 | Minute, second  | 2 | R/W |   |
| 0015H<br>...<br>003BH | Reserved  |   |     |   |
| 003CH                 | Current forward total active energy                     | 4 | R   |   |
| 003EH                 | Current reversing total active energy                   | 4 | R   |   |
| 0040H-03<br>5FH       | Reserved  |   |     |   |
| 0360H                 | Main communication: Communication address and baud rate | 2 | R/W | Address: 1~247<br>Baud rate<br>0:1200<br>1:2400<br>2:4800<br>3:9600<br>4:19200<br>5:38400 |
| 0361H                 | Check bit/ stop bit                                     | 2 | R/W | Check bit:<br>0: None<br>1: Odd<br>2: Even<br>stop bit: 0:1<br>1:1.5<br>2:2               |
| 0362H-03<br>64H       | Reserve   |   |     |   |

|                       |   |      |     |                           |
|-----------------------|---|------|-----|---------------------------|
| 0365H                 | The second communicate: Communication address and baud rate | 2    | R/W |                           |
| 0366H                 | The second communicate: Check bit stop bit                  | 2    | R/W |                           |
| 0367H-03<br>69H       | Reserve   | 6    | R/W | The same as the ADL100-EY |
| 036AH<br>...<br>1FFFH | Reserved  |      |     |                           |
| 2000H<br>...<br>2005H | 4 time zones  | 3×4  | R/W | Time zone table           |
| 2006H<br>...<br>201AH | 14-period of time Parameters setting information            | 3×14 | R/W | The first time list       |
| 201BH<br>...<br>2029H | 14-period of time Parameters setting information            | 3×14 | R/W | The second time list      |

ADL300-EY address table

| Address     | Variable                           | Length | R/W | Notes                             |
|-------------|------------------------------------|--------|-----|-----------------------------------|
| 0000H       | Current total active energy        | 4      | R   |                                   |
| 0002H       | Current spike total active energy  | 4      | R   |                                   |
| 0004H       | Current peak total active energy   | 4      | R   | unit:0.01kWh                      |
| 0006H       | Current flat total active energy   | 4      | R   |                                   |
| 0008H       | Current valley total active energy | 4      | R   |                                   |
| 000AH-000CH | Date, time                         | 6      | R/W | second、minute、hour、day、month、year |
| 000DH-0027H | Reserved                           |        |     |                                   |
| 0028H       | 4 time zones                       | 12     | R/W | Time zone table                   |
| 002EH       | Voltage of A phase                 | 2      | R   |                                   |
| 002FH       | Voltage of B phase                 | 2      | R   | unit: 0.1V                        |
| 0030H       | Voltage of C phase                 | 2      | R   |                                   |
| 0031H       | Current of A phase                 | 2      | R   |                                   |
| 0032H       | Current of B phase                 | 2      | R   | unit: 0.01A                       |
| 0033H       | Current of C phase                 | 2      | R   |                                   |
| 0034H       | Voltage between A-B                | 2      | R   |                                   |
| 0035H       | Voltage between C-B                | 2      | R   | unit: 0.1V                        |
| 0036H       | Voltage between A-C                | 2      | R   |                                   |

|             |   |    |     |   |
|-------------|---|----|-----|---|
| 0037H       | Voltage transfer  | 2  | R/W | Value range (0~9999)  |
| 0038H       | Current transfer  | 2  | R/W | Value range (0~9999)  |
| 0039H-003BH | Reserved  |    |     |   |
| 003CH       | Level 1 password  | 2  | R/W | Value range (0~9999)  |
| 003DH       | Level 2 password  | 2  | R/W | Value range (0~9999)  |
| 003EH-0043H | Reserved  |    |     |   |
| 0046H       | The alarm value 1   | 4  | R/W | unit: 0.01 Yuan   |
| 0048H       | The alarm value 2   | 4  | R/W |   |
| 004AH       | Credit amount   | 4  | R/W |   |
| 004CH-0063H | Reserved  |    |     |   |
| 0064H       | demand  | 2  | R   | unit: 0.001kW   |
| 0065H       | PA  | 4  | R   | unit: 0.001kW   |
| 0067H       | PB  | 4  | R   |   |
| 0069H       | PC  | 4  | R   |   |
| 006BH       | PT  | 4  | R   | unit: 0.001kvar   |
| 006DH       | QA  | 4  | R   |   |
| 006FH       | QB  | 4  | R   |   |
| 0071H       | QC  | 4  | R   | unit: 0.001kVA  |
| 0073H       | QT  | 4  | R   |   |
| 0075H       | SA  | 4  | R   |   |
| 0077H       | SB  | 4  | R   | Calculate the factor: 0.001<br>(-1000~1000) effective range<br>(-1000~1000) |
| 0079H       | SC  | 4  | R   |   |
| 007BH       | ST  | 4  | R   |   |
| 007DH       | PFA   | 2  | R   | Calculate the factor: 0.001<br>(-1000~1000) effective range<br>(-1000~1000) |
| 007EH       | PFB   | 2  | R   |   |
| 007FH       | PFC   | 2  | R   |   |
| 0080H       | PFT   | 2  | R   | Calculate the factor: 0.01  |
| 0081H       | Freq  | 2  | R   |   |
| 0082H-035FH | Reserved  |    |     |   |
| 0360H       | Main communication:<br>Communication address<br>and baud rate | 2  | R/W | The same as the ADL300-EY   |
| 0361H       | The main communication:<br>Check bit stop bit                 | 2  | R/W |   |
| 0362H-1FFFH | Reserved  |    |     |   |
| 2000H       | 14-period of time<br>Parameters setting<br>information        | 42 | R/W | The first time list   |
| 2015H       | 14-period of time<br>Parameters setting<br>information        | 42 | R/W | The first time list   |

There will not be control command because of the page limited, if there are any demand of these command, contact us with no hesitate.

Headquarters: Acrel Co., LTD.

Address: No.253 Yulv Road Jiading District, Shanghai, China

TEL.: 0086-21-69158338 0086-21-69156052 0086-21-59156392 0086-21-69156971

Fax: 0086-21-69158303

Web-site: [www.acrel-electric.com](http://www.acrel-electric.com)

E-mail: [ACREL008@vip.163.com](mailto:ACREL008@vip.163.com)

Postcode: 201801

Manufacturer: Jiangsu Acrel Electrical Manufacturing Co., LTD.

Address: No.5 Dongmeng Road,Dongmeng industrial Park, Nanzha Street,Jiangyin City,Jiangsu Province,China

TEL: 0086-510-86179966

Fax: 0086-510-86179975

Web-site: [www.jsacrel.com](http://www.jsacrel.com)

Postcode: 214405

E-mail: [sales@email.acrel.cn](mailto:sales@email.acrel.cn)